

ICEPURE[®]

SHOWER FILTER

SF001

INSTALLATION INSTRUCTION

What's This For ?

This instruction tells you how to quickly install and start enjoying your new High Output Luxury Shower Filter. The shower filter installs quickly and easily on any standard 1/2" threaded shower arm (the universal size in the U.S.).

Keep water temperature between 40-175 ° F (or 4.44-79.44 ° C)

Tools Required: Teflon Tape (may need in the installation)

1 Flush Shower Filter

Hold the shower filter under a faucet and turn the water on to flush out excess carbon particles from the filter. This results in black water for the first few seconds. Keep flushing for 20 seconds or until the water becomes clear. Turn the shower filter over and flush the other direction.

2 Remove Existing Shower Head

Remove the existing shower head from the shower arm by turning counterclockwise. This can usually be done by hand, but you may need a wrench if your old shower head is too tight. Use your fingers to peel away the old Teflon tape and clean the threaded pipe.

3 Twist On Shower Filter And Head

Place the new shower filter on the shower arm and turn clockwise to tighten by hand. Then twist on your shower head and also tighten by turning clockwise. If additional tightening is needed, use a soft cloth to protect the finish and tighten with a wrench. If any leakage happens, you may need to wrap teflon tape on the threads of your shower filter and the shower arm.

INSTALLATION POSITION

